



## CAST REQUIRED:




### 1 REMOTE ASSEMBLY WITH HANDGRIP ATTACHMENT



#### HELPFUL HINT:

Canon remotes use infrared. Make sure the line of sight between the remote and camera sensor is unobstructed




#### 1A

#### Remote Holder Assembly with Handgrip Attachment

- 1: Assemble remote holder around remote as illustrated above (NOTE: remote not included)
- 2: Screw attachment to remote holder
- 3: Attach Handgrip attachment to Handgrip (NOTE: Handgrip not included)

#### 1B

### 2 REMOTE ASSEMBLY WITH microMOUNT ATTACHMENT



#### 2A

#### Remote Holder Assembly with microMOUNT Attachment

- 1: Assemble remote holder around remote as illustrated above (NOTE: remote not included)
- 2: Screw microMount 15mm stub to remote holder
- 3: microMount can be attached to any 15mm rod on your dSLR kit

#### 2B

