



redrockmicro

Title: DSLR Baseplate Assembly

Scene: Attaching Baseplate to DSLR Cameras and 15mm Rods

CAST REQUIRED:



Cheese Plate



Slider Clamp




existing Rod Clamp



existing microWeight(s)


*NOTE: From your existing microBalance Kit

1




(1) Remove rod clamp from microWeight

2




(2) attach rod clamp to slider

3



- (3a) Attach microBalance Slider to the cheese plate
- (3b) Secure Slider to the cheese plate using knob
- (3c) Secure microWeights to cheese plate using microWeight Screws



ASSEMBLY COMPLETE!
NOW GO SHOOT!!

